




# ANTEC



90016729 ind A



CE

# Notice d'utilisation de l'Abies

**1015414 - CEINTURE ELAGAGE ABIES EN 358-813 S/M**


**1015415 - CEINTURE ELAGAGE ABIES EN 358-813 M/L**

## MATÉRIAUX UTILISÉS :

Sangle principale : polyester, point central : polyamide, dossieret : cordal.

## CARACTÉRISTIQUES:

Ceinture d'élagage conforme à l'EN 358 et l'EN 813, composée de 2 anneaux latéraux pour le maintien au travail (EN 358), de cuissardes semi-rigides à boucles automatiques et d'1 point central en corde démontable (EN 813).



- 1- Point central avec anneau
- 2-Boucles automatiques cuissardes avec protection
- 3-Boucle automatique ceinture
- 4-Maniles
- 5-Anneaux latéraux
- 6-Elastiques de maintien cuissardes
- 7-E m p l a c e m e n t s p o r t e tronçonneuse
- 8-Porte matériel
- 9-Cuissardes
- 10-Dosseret

## INSTRUCTIONS DE RÉGLAGE DE L'ABIES :


Avant toutes choses libérer les sangles de réglage de la triangulation (4 pour les sangles de cuisse, 2 pour les sangles du dossieret).

Ouvrir au plus large les réglages : de triangulation de dossieret, des sangles des cuissardes et des quatre élastiques de soutien de cuissardes.

Instaler un rappel d'élagage muni de son noeud autobloquant à 5-6m de hauteur.

## 1/ RÉGLAGE DE LA SANGLE DE CEINTURE ET POSITIONNEMENT DU DOSSERET

Placer le dossieret au niveau de la ceinture dans le creux des reins, le centrer. Ajuster la «sangle de ceinture». Le dossieret ne doit pas pouvoir glisser sous les hanches.



## 2/ RÉGLAGES DES CUISSARDES

Les cuissardes ont pour fonction l'assise du grimpeur. Elles supportent plus ou moins 70% de son poids.

- 2.1 Tout en restant les pieds au sol s'installer dans le rappel avec son nœud autobloquant. (Fig 1)
- 2.2 Se mettre en opposition, le rappel formant un angle de 45 ° environ par rapport à la verticale du point d'ancrage. (Fig 1)
- 2.3 Positionner les cuissardes sous les cuisses. (Fig 2)
- 2.4 Régler la longueur des sangles des cuissardes de façon :
  - à ne pas être trop serré au niveau des cuisses,
  - à garder le point central réglable ou fixe au plus près.

**Il est important que la coque rigide des cuissardes soit bien centrée sous la cuisse (Fig 2)**

**Pour se faire le réglage des deux sangles sur chaque cuissarde doit être symétrique.**

NB : A ce stade de réglage, il est normal que le dosseret ne soutienne pas le dos.





Fig.2

## 3/ RÉGLAGES DU DOSSERET

Le dosseret a pour fonction le maintien du dos. Il empêche le grimpeur de partir en arrière. Il supporte plus ou moins 30% du poids du grimpeur.

- 3.1 Rester en opposition comme au chapitre 2.2 (Fig 1)
- 3.2 Serrer les sangles de réglage de triangulation du dosseret de manière à se sentir soutenu dans le dos. (Fig 3)
- 3.3 Se mettre en suspension complète, affiner le réglage du dosseret de façon à être soutenu dans le dos.  
Un compromis entre l'opposition et la suspension complète est à trouver.



## 4/ RÉGLAGES DES QUATRE ÉLASTIQUES DE SOUTIEN DE CUSSARDES

Ces élastiques servent à maintenir les cuissardes en place lorsque le grimpeur ne se trouve pas en opposition.

- 4.1 Se remettre en opposition avec le rappel en formant un angle de 45 ° environ par rapport à la verticale du point d'ancrage. (Fig 1) Bien positionner les cuissardes sous les cuisses comme au chapitre 2.3. (Fig 2)

4.2 Ajuster au plus court les quatre élastiques (Fig 4)

4.3 Le réglage est correct si lors du passage de la position debout à la position assise les cuissardes se calent seules sous les cuisses. Du passage assis à debout les cuissardes ne doivent pas tomber au milieu des cuisses.




Fig.4

## 5/ AFFINAGE DES RÉGLAGES

5.1 Contrôler la symétrie des longueurs de réglage.

5.2 Passer le surplus de sangle dans la fente de la boucle.

S'assurer que le retour de sangle couvre le mot « DANGER » et que la flèche jaune sorte du dernier passage. (Fig 5-A)




Fig.5




Fig.6

## 6/ LE POINT CENTRAL RÉGLABLE

Le point central réglable permet d'ajuster la longueur du point central au besoin du grimpeur (position longue en footlock ou retour de branche (Fig 7) et position courte en déplacement dans la tête de l'arbre (Fig 8)). Ne pas régler sous charge.

6.1 Pour ralonger le point central (fig. 7) : tirer sur le sangleon du Ropman (Fig 9-A) et s'asseoir en douceur.

6.2 Pour le raccourcir (fig. 8) : tirer sur le sandalon se trouvant sur la boucle formée par le mou du cordage. (Fig 9-B)



Fig.7




Fig.8




Fig.9

## **REEMPLACEMENT DU POINT CENTRAL FIXE OU RÉGLABLE**

NB : L'Abies est muni d'un point central de 35cm en standard. Celui-ci peut-être remplacé par :

**Réf: 1016210 lg:Point central 30cm**

**Réf: 1016212 lg:Point central 35cm**

**Réf: 1016213 lg:Point central 40cm**

**Réf: 1016214 lg:Point central réglable longueur 0,90m**

### **1 Le point central fixe**

- 1.1 Pour démonter le point central : utiliser une clé Alen N°4 ainsi qu'une pince pour dévisser les 2 maniles.
- 1.2 Mettre le nouveau point central dans l'une des maniles, déposer 2 gouttes de frein filet LOCTITE N°222 sur le filetage de l'axe,
- 1.3 Visser jusqu'au contact et serrer d'un demi tour.
- 1.4 Laisser sécher 15 min avant manipulation et 45 min avant mise en service.
- 1.5 Répéter les opérations 2, 3 et 4 pour l'autre côté.

### **2 Le point central réglable**

- 1.1 Connecter le point central réglable à la manile à droite ou à gauche, du côté de la boucle cousue (Fig 9-C) .  
Se reporter aux étapes du 1.1 à 1.5.
- 1.2 Connecter à l'opposé la boucle cousue et le Ropman à l'autre manile. (Fig 9-D) Se reporter aux étapes du 1.1 à 1.5.



**Respecter la notice spécifique du Ropman, vérifier le sens de blocage de celui-ci et la bonne connexion des deux boucles cousues.**

### **Matériel à utiliser :**


Loctite frein filet 222

Clé Alen N°4

## EMPLACEMENTS PORTE TRONÇONNEUSE



Mise en place  
des bretelles  
de maintien





# Abies

## Instructions for use

1015414 ABIES PRUNING SAFETY BELT EN 358-813 S/M


1015415 ABIES PRUNING SAFETY BELT EN 358-813 M/L

### USED MATERIALS:

Main strap: polyester, central point: polyamide, back support: cordal.

### CHARACTERISTICS:

Pruning safety belt compliant with the EN 358 and EN 813 standards, composed of 2 lateral rings for work positioning (EN 358), semi-rigid leg straps with automatic buckles and 1 central point made with a rope that can be dismantled (EN 813).



- 1- Central point with ring
- 2-Leg straps' automatic buckles with protection
- 3-Belt's automatic buckle
- 4-Shackles
- 5-Lateral rings
- 6-Elastics maintaining leg straps
- 7-Places for the chainsaw carrier
- 8-Tool carrier
- 9-Leg straps
- 10-Back support

### INSTRUCTIONS FOR ADJUSTMENT


First of all, release the adjustment straps from triangulation (4 for the leg loops, 2 for the back support straps). Open at the widest the adjustments of the back support triangulation, the leg straps, and the four elastics maintaining the leg straps.

Instal a pruning abseil with its self-jamming hitch at a height of 5-6m.

#### **1/ ADJUSTMENT OF THE BELT STRAP, AND POSITIONING OF THE BACK SUPPORT**

Put the back support at the level of the belt, in the small of the back, and center it. Adjust the « belt strap ».

The back support mustn't be able to slide under the hips.



## **2/ ADJUSTMENTS OF THE LEG STRAPS**

The leg straps' function is the course of the climber. They withstand more or less 70% of his weight.

2.1 Keeping feet on the ground, settle in the abseil with its self-jamming hitch (Fig 1).

2.2 Place oneself in a layback position; the abseil making an angle of about 45° in relation to the vertical of the anchorage point (Fig 1).

2.3 Position the legs straps under the thighs (Fig 2).

2.4 Adjust the length of the straps of the leg straps in order:

- not to be too tight on the thighs,
- to keep the central point adjustable or fixed at the nearest.

**It is important for the rigid shell**

**of the leg straps to be well**

**centered under the thigh (Fig 2).**

**For that, the adjustment**

**of the two straps**

**on each leg strap must be**


**symmetrical.**

NB: At this stage of the adjustment,

it is right for the back

not to be maintained

by the back support.




## **3/ ADJUSTMENTS OF THE BACK SUPPORT**

The function of the back support is to maintain the back. It prevents the climber from falling backwards. It withstands more or less 30% of the climber's weight.

3.1 Stay in a layback position as in the section 2.2 (Fig 1)

3.2 Tighten the back support's triangulation adjustment straps in order to feel maintained in the back. (Fig 3)

3.3 Place oneself in complete suspension; refine the back support adjustment in order to be maintained in the back. A compromise between the layback and the complete suspension must be found.




## **4/ ADJUSTMENTS OF THE FOUR ELASTICS MAINTAINING THE LEG STRAPS**

The function of these elastics is to maintain the leg straps in place when the climber is not in a layback position.

4.1 Once again, place oneself in a layback position with the abseil making an angle of about 45° in relation to the vertical of the anchorage point (Fig 1). Position the legs straps under the thighs as in the section 2.3 (Fig 2).

4.2 The four elastics must be adjusted at the shortest (Fig 4).

4.3 The adjustment is correct if, during the passage from the standing to the sitting position, the leg straps settle themselves under the thighs. From the standing to the sitting position, the leg straps mustn't fall in the middle of the thighs.



## **5/ REFINING OF THE ADJUSTMENTS**

5.1 Control the symmetry of the adjustment's lengths.

**5.2 Pass the surplus of the strap in the opening of the buckle. Make sure that the return of the strap covers the word « DANGER » and that the yellow arrow goes out from the last passage. (Fig 5-A)**

5.3 Put the slack of the straps in the elastics provided. (Fig 5-B)

5.4 The surplus of the leg straps automatic buckles' strap has to be put within the protections. (Fig 6)




Fig.5




Fig.6

## **6/ THE ADJUSTABLE CENTRAL POINT**

The adjustable central point allows to adjust the length of the central point to the needs of the climber (long position in footlock or in return of branch (Fig 7), and short position for the displacement in the top of the tree (Fig 8)).

Do not adjust under load.

6.1 To lengthen the central point (fig. 7): pull at the Ropman's girth strap (Fig 9-A) and sit down smoothly.

6.2 To shorten it (fig. 8): pull at the girth strap located on the closed loop made by the slack of the rope.(Fig 9-B)




Fig.7




Fig.8




Fig.9

## **REPLACEMENT OF THE FIXED OR ADJUSTABLE CENTRAL POINT**

NB: Abies has a standard central point of 35cm. It can be replaced by:

**Ref: 1016210 lg: Central point 30cm**

**Ref: 1016212 lg: Central point 35cm**

**Ref: 1016213 lg: Central point 40cm**

**Ref: 1016214 lg: Central point adjustable, length 0,90m**

### **1 The fixed central point**

- 1.1 To dismantle the central point: use an Allen key n°4 and a pair of pliers to unscrew the 2 shackles.
- 1.2 Put the new central point in one of the shackles; put 2 drops of LOCTITE frein filet n°222 on the thread of the axle.
- 1.3 Screw on until the contact and tighten a half-turn.
- 1.4 Let dry during 15 min before handling and during 45 min before bringing into service.
- 1.5 Repeat the operations 2, 3, and 4 for the other side.

### **2 The adjustable central point**

- 1.1 Connect the adjustable central point to the shackle on the right or on the left, on the side of the sewed buckle (Fig 9-C). Refer to steps 1.1 to 1.5.
- 1.2 On the opposite side, connect the sewed buckle and the Ropman to the other shackle. (Fig 9-D)  
Refer to steps 1.1 to 1.5.

**Respect specific instructions of the Ropman, check its direction of locking and the good connection of the two sewed buckles.**

### **Equipment to use:**



Loctite frein filet 222

Allen key N°4

## PLACES FOR THE CHAINSAW CARRIER



Set up  
of the shoulder  
straps



**SPERIAN FALL PROTECTION France**  
**35 - 37, rue de la Bidauderie**  
**18100 VIERZON - France**